

Salt and Pepper Mills

/ GVA705



Instruction Manual

12
MONTH

MANUFACTURER'S
WARRANTY

GVA

THE 'V' STANDS
FOR VALUE.

Important Safety Instructions


Store this instruction manual in a safe place, along with your warranty card, purchase receipt and packaging box for future reference. Please pay particular attention to the safety information.

- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Young children should be supervised to ensure that they do not play with the appliance.
- Do not operate the appliance outdoors.
- The appliance should not be operated in a damp place or high humidity (such as the bathroom).
- Do not insert any objects (cutlery, utensils) while the appliance is in operation.
- To reduce the risk of electrocution, never operate this product with wet hands, submerge under water or spill liquids into the product.
- Improper installation may result in the risk of fire, electric shock and or injury to persons.
- The unit has no user-serviceable parts contained within. Do not attempt to repair, disassemble or modify the appliance.

Battery Safety

- Failure to properly align the battery polarity can cause personal injury and/or damage to the mills.
- Keep batteries away from children and pets.
- Do not mix used and new batteries, or mix different battery types.
- Remove spent or expired batteries from the mill. Remove the batteries when the mill will not be used for extended periods of time.
- Never dispose of batteries in a fire.
- Spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local council.
- Each electric mill requires 4 "AA" batteries (not included).

Knowing Your Electric Salt & Pepper Mill



Operation

1. Remove the top cover by twisting anti-clockwise to unlock it. Then remove the plastic retaining sleeve and fit 4 x AA batteries according to the polarity guide. Replace the plastic sleeve to secure the batteries.
2. Pull the motor unit away from the base, and fill the base with either rock salt or peppercorn. Do not over fill - leave about 1cm space in the base.
3. Connect the motor unit to the base, locating the 2 black plastic lugs in the corresponding slots.
4. Replace the top cover by aligning the black arrows on the top cover and base. Twist the top clockwise to lock it into position, give the mill a shake and you are ready to go.
5. Press the button on the top to operate the mill.
6. The screw under the base of the mill allows you to alter the coarseness of the milled pepper or salt. Turn clockwise for a finer grain or anti-clockwise for a more coarse grain.
7. The peppercorns get stuck and the motor is still running, gently shake the unit; sometimes it may be necessary to turn the screw under the mill clockwise to allow for larger peppercorns.

Care & Cleaning Instructions

- Using a brush, remove any residual matter from the mill.
- Use a damp cloth to clean the mill, dry with a soft cloth.
- Do not use water or other liquids or solvents to clean the mill.

Storage

- Remove the batteries if left unused for long periods.
- Store the units in a cool, dry place.