

In-Car Bluetooth Speakerphone

/ GVABT470



Instruction Manual

12
MONTH

MANUFACTURER'S
WARRANTY

GVA

THE 'V' STANDS
FOR VALUE.

IMPORTANT SAFEGUARDS



READ ALL INSTRUCTIONS BEFORE USE.



WARNING-- To reduce the risk of fire, electric shock, or serious personal injury:

- Keep this product out of reach of children and pets. Do not leave the product unattended while it is plugged in.
- Do not plug/unplug the charger into/from a vehicle outlet with wet hands



CAUTION-- To reduce the risk of personal injury:

- Always ensure the product is off while charging.
- Do not use the charger if it has been damaged or if it is dropped in or exposed to water.

NOTICE-- To reduce the risk of product and/or property damage:

- This product is intended solely for non-commercial, non-industrial use.
- To disconnect the product after charging, pull directly on the charger; do not pull on the power cord.

- Do not subject the product to excessive force, violent shocks, extreme temperatures/humidity levels, or lengthy periods of direct sunlight.
- Do not attempt to repair the product as it contains no user-serviceable parts.
- Use the product away from computer monitors or other electronic devices to reduce possible interference.
- Do not immerse the product in water or other liquids.
- Do not use liquid or abrasive cleaners to clean the product; use a soft, dry cloth only.
- Do not use the Speakerphone for other than its intended use.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

Contents

- Bluetooth Speakerphone
- Car Charger
- Visor Clip
- Rechargeable Lithium-Ion Battery
- Instruction Manual

Parts

- 1.Mute Button
- 2.LED Indicator
- 3.Microphone
- 4.Function Button

- 5.Volume - Button
- 6.Volume + Button
- 7.Mini USB Port
- 8.Speaker



To Set Up

To begin using the Speakerphone:

1.Install the Battery

- Slide the battery compartment cover in the direction of the arrow to remove.
- Install the battery, aligning the contacts on the battery with the contacts in the compartment, and then replace the cover.

2.Charge the Speakerphone

NOTICE: Do not use a charger other than the one provided to charge the Speaker, and do not use the Speaker while it is being charged.

NOTE: After repeated charging, battery power will gradually deteriorate and will eventually be depleted; this is normal. The battery is replaceable(refer to “Specifications” at the back of this manual for the battery model details).

1. Ensure the Speakerphone is OFF during charging.
2. Connect the mini USB (small end) of the car charger to the Mini USB port on the side of the Speakerphone and then plug the other end into the 12-volt outlet of a vehicle. The LED indicator on the Speakerphone will illuminate red. Allow it to fully charge for 2-3 hours.
3. The LED indicator will turn off once the battery is fully charged. Disconnect the charger from the vehicle and then remove the mini USB connector from the Speakerphone, it is now ready to be used.

3.Power ON/OFF the Speakerphone.

NOTE: To conserve battery power, power OFF when not in use.

- To power ON, press and hold the Function Button for about 5 seconds until you hear a single tone sound, the LED Indicator will flash blue 5 times rapidly. The Speakerphone is now in Standby mode (blue LED flashes slowly every 3 seconds)
- To power OFF, press and hold the Function Button for about 5 seconds until you hear a double tone sound. The LED indicator will flash red 5 times and then shut off.

4. Pair (Link) the Speakerphone with a compatible mobile phone with Bluetooth.

NOTE: Pairing only needs to be completed once. Each time the Speakerphone is switched on it will automatically connect with your phone if it is within range and Bluetooth activated on your phone.

1. Ensure the Speakerphone is off.
2. Press and hold the Function Button until you hear the double tone sound. (Please note you will hear the single tone sound as you would when you power ON the device, you will need to keep holding the Function button for another 5 seconds). The LED indicator will flash red and blue after the double tone sound.

3. Activate the Bluetooth feature on the mobile phone and set it to search for Bluetooth devices, selecting "BCK08A" from the list of devices. Once it has been paired there will be a single beep to indicate it is now paired, and the LED indicator will flash blue slowly in standby mode.

NOTE: This will work if the Bluetooth function on your phone is Version 2.1 or above. Refer to your mobile phone's instruction manual, if below 2.1 refer to point 6 below.

4. If the pairing cannot be completed within 2 minutes after the pairing mode is activated, please repeat the same steps above to try pairing your mobile phone to the Speakerphone.

5. To disconnect your mobile phone from the Speakerphone, power OFF the Speakerphone then go into your Bluetooth devices on your phone and disconnect "BCK08A".

6. If the Bluetooth function on your mobile phone is below Version 2.1, you will need to enter the pass code "0000" to link the Speakerphone to the mobile phone. If pairing is successful, the Blue Indicator will flash 3 times.

NOTE: If pairing is not successful, repeat all steps.

5.Using the Speakerphone

1.Answering a call – When receiving a phone call, press the Function button once to answer a call.

2.Ending a call – Press the Function button once to end a call.

3.Rejecting a call – When you hear the ringing tone, press and hold the Function button for 2 seconds to reject the call.

4.Last Number Redial – Press and hold the VOLUME+ button for 2 seconds.

5.Adjusting the Volume – During a call, press the V+ or V- adjust the volume to your desired volume level.

6.Mute Function – During a call, press and hold the Mute button for 3 seconds. The LED indicator will flash red once and also beep twice when the mute function is activated, and will also beep twice every 3 seconds to remind you the call is in mute mode.

Visor Clip Installation (optional):

To install, insert the hook of the Clip into the notch on the back of the Speakerphone and push down to secure.

Indicators and Tones

Powering On	Tone sounds and Blue Indicator flashes five times rapidly
Pairing	Double tone sounds and Blue and Red Indicators flash alternately
Standby	Blue Indicator flashes slowly
Connecting	Blue Indicator flashes slowly
Making/Answering a Call	Blue Indicator flashes rapidly
On a Call	Blue Indicator flashes slowly
Reject a call	Long tone sounds
Low Battery	Red Indicator illuminates
Powering Off	Tone sounds and Red Indicator flashes five times rapidly
Mute	The LED flashes red 1 second when you long press "mute" button, there will be a warning beep every 3 seconds when mute is activated. The LED indicator will then revert to slow flashing blue.
Charging	Red Indicator illuminates and then turns off when charging complete

Specifications

- Bluetooth v3.0, Class II
- Integrated with echo cancellation and noise suppressor
- Built-in speaker and microphone
- Operating Frequency Band: 2.4GHz ~ 2.48GHz unlicensed ISM band
- Operating distance: up to 10 meters (32 feet)
- Battery type: Rechargeable Lithium Polymer Battery 3.7V, 750mAh
- Charging time: approximately 2-3 hours
- Talk time: approximately 6 hours**
- Standby time: approximately 25 days**
- Dimensions: 117.5 x 47 x 15.3 mm

**Times vary depending on the type of phone, usage settings, and environment.

GVABT470



5 6 1 3

Made in China

**Bluetooth is a registered trademark of
Bluetooth SIG, Inc. and is used under
license.**